A.


Antenna Connector
Antenna
Back of Stereo
Line Out Phono
Connectiors
Wiring Socket
Wire Harness
Speaker
Wires
Amp Remote Turn On
(To Optional Equipment)
Blue/White
Black
Ground (–)
(To Chassis Ground)
Yellow
Red
Clock Memory
(To Battery +)
Power Lead
(To ACC)

B.


Back of Stereo
Wiring Socket
Wire Harness
Line Out Phono
Connectors
White
White/Black
Front Left
Speaker
Gray
Gray/Black
Front Right
Speaker
Green
Green/Black
Rear Left
Speaker
Violet
Violet/Black
Rear Right
Speaker
Power
Wires
Connecting
4 Speakers
White
Green/Black
Left
Speaker
Gray
Violet/Black
Right
Speaker
Connecting
2 Speakers

C.


Antenna Socket
Antenna
Back of Stereo
Wiring Socket
Line-out
Line-out
Red
White
Black
Ground
Speaker Wires
Power Sources
Ground Wire
Equalizer/ Booster
Wiring Socket
Rear Right Speaker
Violet
Violet/Black
Black
Ground
Red
Battery
Rear Left Speaker
Green
Green/Black
Front Right Speaker
Gray
Gray/Black
Front Left Speaker
White
White/Black